



# INTEK SLI INSTRUCTIONS FOR USE

INTEK SLI is administered into toilets/urinals **twice** daily to prevent scale build-up in the ships Black Water lines.

## To Prepare For Use:

Fill the **reusable** measure-and-pour bottle (supplied by INTEK) with INTEK SLI to the 4oz. mark then, add tap water to fill the bottle to the 32 oz mark (one quart).



After adding INTEK-SLI, fill Mix-and-Pour bottle to 32 oz mark with tap water →



Fill Mix-and-Pour bottle to ←4 oz mark with INTEK-SLI

## To Administer INTEK SLI:

**First, following normal cleaning procedures, clean and flush the toilet or urinal.** After toilet/urinal is cleaned and flushed, squeeze the measure-and-pour bottle to fill the reservoir to **1 oz**, pour solution into toilet/urinal and flush.



## Notes:

**INTEK SLI must be administered twice daily to achieve optimum results.**

INTEK SLI is non-hazardous, non-acidic and non-caustic. If spilled, simply wipe up and dispose of in trash.

**Measure and pour bottles are REUSABLE!** Should replacement bottles be required they are available from INTEK (through normal procurement procedures) at a cost of \$50.00 per case of 12 plus shipping.